



Position the secondary switch housings in the lowest position. Remove the keycaps with a standard keycap pliers and then release the switches with the conventional method by pressing in the retaining clips.

Pull the switch out of the housing by a **maximum** of 3 cm. Please check the mounting direction of the adapter.



**Attention:**

Any liability and warranty is void if the pushbuttons are changed independently.

Pull off the adapter and change the switch.

**Remark:**

Check that the adapter is parallel with the housing of the switch. First position and center one adapter pin opening on one switch pin and carefully guide the adapter at a slight angle over the central pin onto the second switch pin. Only now press the adapter completely onto the switch. Please be careful here and make sure that the pins are correctly aligned with the openings before you press the adapter on completely, otherwise they can be damaged. Now reassemble the switch in reverse order.

